Samsung Blackjack Battery Cover Replacement

Remove the battery cover on your Samsung Blackjack.

Written By: Everett



INTRODUCTION

Use this guide to replace the battery cover and access the phone battery and SIM card.

Step 1 — Battery Cover







- Hold the device with the screen facing away from you and the camera towards you.
- Place your thumb on the bottom half of the phone and slide the cover off while gently pushing down on the cover.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 07:52:20 PM.